

PORK SAFETY

Title: Post-Process Pasteurization of Packaged, Ready-to-Eat products for Control of *Listeria monocytogenes*- **NPB# 01-110**

Investigator: Harshavardhan Thippareddi

Institution: Kansas State University,

Co-Investigators: A. Reicks, R.K. Phebus, J.L. Marsden, and C.L. Kastner

Date Received: 5/2/2002

Abstract

The efficacy of a saturated steam-based post-process pasteurization system to reduce/eliminate *L. monocytogenes* on frankfurters and restructured hams was evaluated. Frankfurters were packaged in a single layer format (4 per package), rinsed with lactic acid (2 or 4%) and pasteurized to end point surface temperatures of 160, 170 and 180 °F. In addition, frankfurters were individually packaged and treated with lactic acid (2 or 4%), vacuum packaged and pasteurized to end-point surface temperatures of 160, 170 and 180 °F. Similarly, restructured hams (half hams) were treated with lactic acid (2 or 4%), vacuum packaged and pasteurized for 2 or 4 min.

Pasteurization of inoculated single layer franks to target surface end point temperatures of 160, 170 and 180 °F resulted in *L. monocytogenes* reductions ($p \leq 0.05$) of 0.92, 1.44 and 2.89 log CFU/frank, respectively. Treatment of the franks with lactic acid at either 2 or 4% did not result in greater ($p > 0.05$) *L. monocytogenes* reductions. Greater reductions in *L. monocytogenes* reductions were observed when the frankfurters were individually packaged, with 2.33, 4.63 and 6.52 log CFU/Frank reductions at target surface end point temperatures of 160, 170 and 180 °F. Pasteurization of hams (half) for 2 and 4 min resulted in *L. monocytogenes* reductions ($p \leq 0.05$) of 2.03 and 4.14 log CFU/Sq. Cm., respectively. Lactic acid treatment at either 2 or 4 % did not result in greater ($p > 0.05$) *L. monocytogenes* reductions. Surface pasteurization of frankfurters resulted in minimal, but statistically significant increases ($p \leq 0.05$) in surface hardness values and lower L^* values compared to the nontreated controls. However, the a^* and b^* values were not affected by heat treatments. Pasteurization of hams did not result in changes ($p > 0.05$) in the color values (L^* , a^* and b^*) of the ham surfaces.

Post process pasteurization of frankfurters (in-package) and hams using saturated steam based Stork-RMS Protecon system is effective in reducing the risk of *L. monocytogenes*

These research results were submitted in fulfillment of checkoff funded research projects. This report is published directly as submitted by the project's principal investigator. This report has not been peer reviewed

For more information contact:

National Pork Board, P.O. Box 9114, Des Moines, Iowa USA

800-456-7675, Fax: 515-223-2646, E-Mail: porkboard@porkboard.org, Web: <http://www.porkboard.org/>